


DVK720 Expansion Board

Driver Porting Manual

2014. 04. 03 V1. 0



Copyright Statement

All rights reserved by Waveshare Electronics Co., Ltd.
Not allow to modify, distribute, or copy without permission.

Revision history

Version	Date	Description
V1.0	2014.04.03	Initial Release

Content

Copyright Statement	I
Revision history	I
1. Porting keypad driver	1
1.1 Configure the pin	1
1.2 Add platform resources	2
2. Porting PWM driver	3
2.1 Configure the pins	3
2.2 Add platform resources	3
3. Porting LED driver	4
3.1 Configure the pins	4
3.2 Configure the kernel	4
4. Porting SPI driver	5
4.1 Configure the pins	5
4.2 Add platform resources	6
5. Porting UART driver	9
5.1 Configure the pins	9
6. Porting DS18B20 driver	9
6.1 Configure the pins	9
6.2 Configure the kernel	10
7. Porting RS485	10
7.1 Add pins configuration	10

7.2 Configure the kernel.....	11
8. Porting the USB NIC driver	11
8.1 Add driver source code	11
8.2 Configure the kernel.....	11

Document formatting convention

1. Commands on PC ubuntu terminal: preceding with '#', root user privileges is requested;
2. Commands on the board terminal: preceding with '\$'.

1. Porting keypad driver

1.1 Configure the pin

1) Add the pins initialization configure to structure `mx6q_sabresd_cstm_tq_pads` in file `arch/arm/mach-mx6/board-mx6q_sabresd.h`

```
#vi arch/arm/mach-mx6/board-mx6q_sabresd.h
```

```
MX6Q_PAD_EIM_D17__GPIO_3_17,
```

```
MX6Q_PAD_EIM_D30__GPIO_3_30,
```

```
MX6Q_PAD_ENET_TX_EN__GPIO_1_28,
```

```
MX6Q_PAD_EIM_D20__GPIO_3_20,
```

```
MX6Q_PAD_CSI0_DAT10__GPIO_5_28,
```

```
MX6Q_PAD_EIM_D18__GPIO_3_18,
```

```
MX6Q_PAD_ENET_TXD0__GPIO_1_30,
```

```
MX6Q_PAD_EIM_D23__GPIO_3_23,
```

1) Add macro definition to configuration file

arch/arm/mach-mx6/board-mx6q_sabresd.c:

[#vi arch/arm/mach-mx6/board-mx6q_sabresd.c](#)

```
#define SABRESD_BUTTON1 IMX_GPIO_NR(3,17)
```

```
#define SABRESD_BUTTON2 IMX_GPIO_NR(3,30)
```

```
#define SABRESD_BUTTON3 IMX_GPIO_NR(1,28)
```

```
#define SABRESD_BUTTON4 IMX_GPIO_NR(3,20)
```

```
#define SABRESD_BUTTON5 IMX_GPIO_NR(5,28)
```

```
#define SABRESD_BUTTON6 IMX_GPIO_NR(3,18)
```

```
#define SABRESD_BUTTON7 IMX_GPIO_NR(1,30)
```

```
#define SABRESD_BUTTON8 IMX_GPIO_NR(3,23)
```

1.2 Add platform resources

1) Add below to board-mx6q_sabresd.c:

[#vi arch/arm/mach-mx6/board-mx6q_sabresd.c](#)

```
static struct gpio_keys_button sabresd_buttons[] = {
```

```
GPIO_BUTTON(SABRESD_BUTTON1, KEY_1, 1, "button1", 0, 1),
```

```
GPIO_BUTTON(SABRESD_BUTTON2, KEY_2, 1, "button2", 0, 1),
```

```
GPIO_BUTTON(SABRESD_BUTTON3, KEY_3, 1, "button3", 0, 1),
```

```
GPIO_BUTTON(SABRESD_BUTTON4, KEY_4, 1, "button4", 0, 1),
```

```
GPIO_BUTTON(SABRESD_BUTTON5, KEY_5, 1, "button5", 0, 1),
```

```
GPIO_BUTTON(SABRESD_BUTTON6, KEY_6, 1, "button6", 0, 1),
```

```
GPIO_BUTTON(SABRESD_BUTTON7, KEY_7, 1, "button7", 0, 1),
```

```
GPIO_BUTTON(SABRESD_BUTTON8, KEY_8, 1, "button8", 0, 1),  
}
```

2. Porting PWM driver

2.1 Configure the pins

Add the pins initialization configure to structure
mx6q_sabresd_cstm_tq_pads in file
arch/arm/mach-mx6/board-mx6q_sabresd.h

```
#vi arch/arm/mach-mx6/board-mx6q_sabresd.h
```

```
MX6Q_PAD_SD1_CMD__PWM4_PWMO,
```

2.2 Add platform resources

Add platform resources to board-mx6q_sabresd.c.

```
#vi arch/arm/mach-mx6/board-mx6q_sabresd.c
```

```
static struct platform_pwm_backlight_data
```

```
mx6_marsboard_pwm3_backlight_data = {
```

```
    .pwm_id = 3,
```

```
    .max_brightness = 255,
```

```
    .dft_brightness = 128,
```

```
    .pwm_period_ns = 50000,
```

```
};
```

```
static void __init mx6_sabresd_board_init(void){
    imx6q_add_mxc_pwm_backlight(3,&mx6_marsboard_pwm3_backlight_data);
}
```

3. Porting LED driver

3.1 Configure the pins

Add the pins initialization configure to structure mx6q_sabresd_cstm_tq_pads in file board-mx6q_sabresd.h

```
#vi arch/arm/mach-mx6/board-mx6q_sabresd.h
```

```
MX6Q_PAD_CSI0_PIXCLK__GPIO_5_18,
```

```
MX6Q_PAD_CSI0_VSYNC__GPIO_5_21,
```

```
MX6Q_PAD_CSI0_DAT17__GPIO_6_3,
```

```
MX6Q_PAD_CSI0_DAT13__GPIO_5_31,
```

3.2 Configure the kernel

Copy the whole source code file /ws_driver to kernel directory drivers/char (led.c driver file included in directory ws_driver), modify Kconfig and Makefile under directory driver/char, add the driver file in file ws_driver to the kernel.

Add below to Kconfig

```
#vi driver/char/Kconfig
```

```
source "drivers/char/ws_driver/Kconfig"
```

```
#vi driver/char/Makefile
```

Add

```
obj-y += ws_driver/
```

```
#make menuconfig
```

```
Device Drivers --->
```

```
Character devices --->
```

```
ws_add_drivers --->
```

```
[*] LED support
```

4. Porting SPI driver

4.1 Configure the pins

Add the pins initialization configure to structure mx6q_sabresd_cstm_tq_pads in file board-mx6q_sabresd.h.

```
#vi arch/arm/mach-mx6/board-mx6q_sabresd.h
```

```
MX6Q_PAD_EIM_CS0__ECSPI2_SCLK,
```

```
MX6Q_PAD_EIM_CS1__ECSPI2_MOSI,
```

```
MX6Q_PAD_EIM_OE__ECSPI2_MISO,
```

```
MX6Q_PAD_CSI0_DAT11__ECSPI2_SS0,
```

4.2 Add platform resources

1) Add SPI platform resources

```
#vi arch/arm/mach-mx6/board-mx6q_sabresd.h
```

```
static int mx6q_sabrelite_spi2_cs[] = {  
    MX6Q_SABRELITE_ECSPi2_CS1,  
};  
  
static const struct spi_imx_master mx6q_sabresd_spi2_data  
__initconst = {  
    .chipselect = mx6q_marsboard_spi2_cs,  
    .num_chipselect = ARRAY_SIZE(mx6q_marsboard_spi2_cs),  
};  
  
imx6q_add_ecspi(0, &mx6q_sabrelite_spi2_data);  
  
static struct mtd_partition imx6_sabrelite_spi_nor_partitions[] = {  
    {  
        .name = "bootloader",  
        .offset = 0,  
        .size = 0x00100000,  
    },  
    {  
        .name = "kernel",
```

```

        .offset = MTDPART_OFS_APPEND,

        .size = MTDPART_SIZ_FULL,
    },
};

static struct flash_platform_data imx6_sabrelite__spi_flash_data = {

    .name = "spidev",

    .parts = imx6_sabrelite_spi_nor_partitions,

    .nr_parts = ARRAY_SIZE(imx6_sabrelite_spi_nor_partitions),

    .type = "sst25vf016b",
};

static struct spi_board_info imx6_sabrelite_spi_nor_device[]
__initdata = {

    {

        .modalias = "spidev",

        .max_speed_hz = 12000000, /* max spi clock (SCK) speed
in HZ */

        .bus_num = 1,

        .chip_select = 0,

        .platform_data = &imx6_sabrelite__spi_flash_data,
    },
};

```

```
static void spi_device_init(void)
{
    spi_register_board_info(imx6_sabrelite_spi_nor_device,
        ARRAY_SIZE(imx6_sabrelite_spi_nor_device));
}
```

2) Configure the kernel

#make menuconfig

```
Device Drivers --->
    [*] SPI support --->
        <*> User mode SPI device driver support
```

3) Add SPI chip select signal driver

ws_driver copied in "Chapter 3.2 Configure the kernel" includes driver source code spi_io.c for SPI chip select signal.

Execute below in top-level directory of the kernel source code:

#make menuconfig

```
Device Drivers --->
    Character devices --->
        ws_add_drivers --->
            [*] spi2_cs
```

5. Porting UART driver

5.1 Add pins configuration

- 1) Add the pins initialization configure to structure `mx6q_sabresd_cstm_tq_pads` in file `board-mx6q_sabresd.h`.

```
#vi arch/arm/mach-mx6/board-mx6q_sabresd.h
```

```
MX6Q_PAD_CSI0_DAT14__UART5_TXD,
```

```
MX6Q_PAD_CSI0_DAT15__UART5_RXD,
```

- 2) Comment out below code in structure static `iomux_v3_cfg_t` `mx6q_sabresd_csi0_sensor_pads[]`:

```
MX6Q_PAD_CSI0_DAT12__IPU1_CSI0_D_12,
```

```
MX6Q_PAD_CSI0_DAT13__IPU1_CSI0_D_13,
```

```
MX6Q_PAD_CSI0_DAT14__IPU1_CSI0_D_14,
```

```
MX6Q_PAD_CSI0_DAT15__IPU1_CSI0_D_15,
```

```
MX6Q_PAD_CSI0_DAT16__IPU1_CSI0_D_16,
```

```
MX6Q_PAD_CSI0_DAT17__IPU1_CSI0_D_17,
```

6. Porting DS18B20

6.1 Add pins configuration

- 1) `ws_driver` copied in "Chapter 3.2 Configure the kernel" includes driver source code `ds18b20.c`.

Add the pins initialization configure to structure mx6q_sabresd_cstm_tq_pads in file board-mx6q_sabresd.h.

```
#vi arch/arm/mach-mx6/board-mx6q_sabresd.h
```

```
MX6Q_PAD_EIM_D21__GPIO_3_21,
```

6.2 Configure the kernel

```
#make menuconfig
```

```
Device Drivers --->
```

```
Character devices --->
```

```
ws_add_drivers --->
```

```
[*] DS18B20 support
```

7. Porting RS485

7.1 Add pins configuration

1) ws_driver copied in "Chapter 3.2 Configure the kernel" includes driver source code RS485.c.

Add the pins initialization configure to structure mx6q_sabresd_cstm_tq_pads in file board-mx6q_sabresd.h.

```
#vi arch/arm/mach-mx6/board-mx6q_sabresd.h
```

```
MX6Q_PAD_CSI0_DAT18__GPIO_6_4,
```

```
MX6Q_PAD_CSI0_DAT19__GPIO_6_5,
```

7.2 Configure the kernel

#make menuconfig

```
Device Drivers --->
```

```
Character devices --->
```

```
ws_add_drivers --->
```

```
[*] RS485 support
```

8. Porting USB NIC driver

8.1 Add driver source code

- 1) Copy source code /rtl8192cu to kernel file drivers/net/wireless, modify related file Makefile and Kconfig:

#vi drivers/net/wireless/Makefile

Add

```
obj-$(CONFIG_RTL8192CU) += rtl8192cu/
```

#vi drivers/net/wireless/Kconfig

Add

```
source "drivers/net/wireless/rtl8192cu/Kconfig"
```

8.2 Configure the kernel

#make menuconfig

```
Device Drivers --->
```

[*] Network device support --->

[*] Wireless LAN --->

< * > RtalteX 8192c usb wifi